







**ADA Inground Table  
Mount Instructions  
BM1235**

REV# 2  
8-19-2016




# ADA Inground Table Mount Instructions BM1235




**HARDWARE &  
TOOLS REQUIRED  
FOR ASSEMBLY**

**2/7**


# ADA Inground Table Mount Instructions BM1235




32  
3-1/2" X 5/16"  
CARRIAGE BOLT




32  
5/16" SERRATED  
FLANGE NUTS




8  
5-3/4" X 7/16"  
HEX BOLTS



4  
1-1/8" x 3/8"  
HEX BOLTS



8  
7/16" HEX NUT



4  
3/8" HEX NUT

## REQUIRED TOOLS (NOT INCLUDED)

- 1 - 1/2" SOCKET
- 1 - 9/16" WRENCH
- 1 - 9/16" SOCKET
- 1 - 5/8" WRENCH
- 1 - 5/8" SOCKET


**NOTE: IT IS IMPORTANT TO KEEP ALL BOLTS FINGER TIGHT DURING ASSEMBLY UNTIL ENTIRE TABLE IS ASSEMBLED**

**HARDWARE &  
TOOLS REQUIRED  
FOR ASSEMBLY**

# ADA Inground Table Mount Instructions BM1235


## STEP 1 Mount Center Post

- Dig a 30 inch deep by 8 inch diameter hole in the ground
- Stand the center post up right and perpendicular to the ground
- Guide wires or some other form of support may need to be added to the center post until the concrete hardens



## STEP 2 Seat Frame Assembly


- Bolt two seat supports (C) to opposite sides with four 5-3/4" x 7/16" hex bolt (H) and four 7/16" hex nuts
- Repeat for the remaining seat support



# ADA Inground Table Mount Instructions BM1235


## STEP 3 Top Support Assembly

- Slide the top support frame (B) over the top to the center post (A)
- Align the holes in the center post and the top support frame
- Secure the top support frame (B) to the center post (A) with four 1-1/8" x 3/8" hex bolts (I) and four 3/8" hex nuts (K)



## STEP 3 Top Assembly



- Place the board with the umbrella hole (D) in the center of the top support frame (B)
- Place four other boards (E) on the top support frame (B)
- Secure the boards to the top support frame with twenty 3-1/2" x 5/16" carriage bolts (F) and 5/16" flange nuts (G)



# ADA Inground Table Mount Instructions BM1235




## STEP 4 Seat Assembly

- Place a board (E) over the seat support frame (C)
- Align the holes in the board with the holes in the frame
- Secure the board to the frame with four 3-1/2" x 5/16" carriage bolts (F) and 5/16" flange nuts (G)
- Repeat for each seat area



# ADA Inground Table Mount Instructions BM1235

REV# 2  
8-19-2016



BURY POST 30 INCHES INTO  
THE GROUND

ALL DIMENSIONS ARE IN INCHES