








**Solid Plastic Top Walk-
Thru ADA Table
Instructions BM1460**

REV # 2
6/21/2023



Solid Plastic Top Walk-Thru ADA Table Instructions BM1460




REQUIRED TOOLS (NOT INCLUDED)

- 1 - 1/2" WRENCH
- 1 - 1/2" SOCKET


**HARDWARE &
TOOLS REQUIRED
FOR ASSEMBLY**

2/7


Solid Plastic Top Walk-Thru ADA Table Instructions BM1460




76
5/16" WASHER
WUSS031WAS188




3
5/16" NUT
NFHX031CNUT188



1
5/16-18 X 1" HEX BOLT
HHCS031C100188



2
5/16-18" X 3" CARRIAGE BOLT
CARR031C300188




72
5/16" X 1.25" LAG SCREW
HLAG031C125188

Solid Plastic Top Walk-Thru ADA Table Instructions BM1460


STEP #1 Tabletop Assembly

- Lay three boards (D) on a flat clean surface with alignment marks visible
- Lay table top support (A) on 3 boards (D) aligning holes with the alignment marks
- Secure lag screws (K) thru washers (G) thru table top support (A) into plastic boards (D)



STEP #2 Seat Assembly

- Lay one board (E) top side down on a flat clean surface
- Lay seat support (B) on board (E) aligning holes with the flat side down
- Secure lag screws (K) thru washers (G) thru table top support (A) into plastic board (E)
- Repeat for remaining board (E) and seat support (B)





Solid Plastic Top Walk-Through ADA Table

Instructions BM1460



STEP #3 Installing Plastic End Supports

- Stand plastic end supports (F) upright, 50.0" apart
- Set assembled top from Step #1 on top of plastic ends (F)
- Attach top assembly to plastic ends (F) with lag screws (K) thru washers (G) thru table top support (A) into plastic ends (F) making sure ends are at 90 degrees




STEP #4 Installing angle support braces

- Place a 5/16" x 1" hex bolt (I) thru washer (G) the two angle support braces (C) and table top support (A) and hand tighten with a nut (H) See DETAIL 1
 - Attach the angle support braces (C) to the plastic ends (F) with 5/16" x 3" carriage bolts (J) thru plastic ends (F) thru angle support (C) thru washer (G) to nut (H) See DETAIL 2
 - Tighten all nuts and bolts



Angle support brace connection to plastic end support






Angle support brace connection to center channel

Solid Plastic Top Walk-Thru ADA Table Instructions BM1460

STEP #5 Installing Seats

- Set assembled seats from Step #2 on top of plastic ends (F)
- Attach seat assembly to plastic ends (F) with lag screws (K) thru washers (G) thru seat support (B) into plastic ends (F)
- Repeat for other seat







**INSTALLING
SEATS**

6/7

Solid Plastic Top Walk-Thru ADA Table Specifications BM1460

REV #2
6/21/2023



ALL DIMENSIONS ARE SHOWN IN INCHES