



4-LEGGED PATIO TABLE ASSEMBLY INSTRUCTIONS

KCF3050
REV. 1
6/18/24



4-LEGGED PATIO TABLE ASSEMBLY INSTRUCTIONS




UMBRELLA BOARD
QTY. = 2



MIDDLE BOARD
QTY. = 2

END BOARD IS
DIFFERENT FROM
MIDDLE BOARD
BY THE PLACEMENT
OF THE HOLES ON
THE END.



END BOARD
QTY. = 2

REQUIRED TOOLS (NOT INCLUDED)

#2 PHILLIPS SCREWDRIVER

POWER DRILL

#2 PHILLIPS BIT

5/32" ALLEN WRENCH

**BOARDS FOR
4-LEGGED TABLE**

1/4

4-LEGGED PATIO TABLE ASSEMBLY INSTRUCTIONS





TABLE TOP FRAME
QTY. = 1



LEGS
QTY. = 4




1/4-20 x 1/2" BUTTON HEAD
FLANGED MACHINE SCREW
QTY. = 12



#10 X 3/4" PAN
HEAD SCREWS
QTY. = 36

4-LEGGED PATIO TABLE ASSEMBLY INSTRUCTIONS




STEP 1: PLACE TABLE TOP WELDMENT ON A FLAT, SMOOTH, AND CLEAN SURFACE.

STEP 2: STAND UP ONE LEG AT A TIME IN EACH CORNER AS SHOWN AND START EACH 1/4-20 X 1/2" MACHINE SCREW.

STEP 3: TIGHTEN WITH A 5/32" ALLEN WRENCH.

STEP 4: REPEAT FOR ALL (4) LEGS AND GO BACK CHECK FOR TIGHTNESS OF SCREWS.

4-LEGGED PATIO TABLE ASSEMBLY INSTRUCTIONS



STEP 5: AGAIN, ON A SMOOTH, CLEAN AND FLAT SURFACE, ARRANGE ALL (6) BOARDS AS SHOWN. PUT THE UMBRELLA BOARDS TOGETHER WITH THE HALF-CIRCLE CUTOUTS FACING EACH OTHER. THEN PUT THE MIDDLE BOARDS NEXT TO THEM. THEN PLACE THE END BOARDS NEXT TO THEM.

STEP 6: PLACE THE PREVIOUSLY ASSEMBLED METAL FRAME ON TOP OF THE BOARDS AS SHOWN. LINE UP THE SCREW HOLES IN THE METAL FRAME WITH THE HOLES IN THE BOARDS. START THE SCREWS BY HAND WITH A PHILLIPS SCREWDRIVER.

STEP 7: ONCE ALL (36) SCREWS ARE STARTED, FINISH TIGHTENING WITH A PHILLIPS BIT IN A POWER DRILL, BEING CAREFUL TO NOT OVER TIGHTEN AND STRIP THE SCREWS.

4-LEGGED PATIO TABLE SPECS

KCF3050
REV. 1
6/18/24

